
Features Transaxle Yo-Yo




Common Questions

For related videos and downloads visit www.NEDkids.com

How do I wind up the string when it keeps slipping?

Wrap the string over your finger once. Then continue to wrap the string around the axle, to the side of your finger, 2-3 times. Simply remove your finger and gently finish winding up the string. The finger loop will disappear when you throw the yo-yo down.



Can a ball bearing yo-yo be set for easy play?

This yo can be hitched for easy play, as well as unhitched for advanced tricks. It will take five wraps to make it stop 'sleeping' completely, for easier tricks. See the "How to add the hitch for beginner tricks" instructions in the section below.

Adding wraps to make a hitch (for easy play)


The Zip Yo comes as a sleeper



VO.


1. Pinch the string about 3 inches (7cm) above your

2. As you look down at your yo-yo, spin it counterclockwise until the strands of string split apart.





4. Let go of the pinched string, and the yo-yo will spin, returning the string to its natural position. Now you are ready for easy play!



More Info

NEVER GIVE UP ★ ENCOURAGE OTHERS ★ DO YOUR BEST®



- Visit www.MindsetMission.com/product-videos.html
- If a part is missing, exchange the yo for a new one and return with remaining inventory for full credit.
- Questions? Visit the Product Help Center at: at www.mindsetmission.com/product-help-center.html

